

<b>Interface To</b>	<b>Purpose</b>
memory	Access to storage for packet buffers, queues, instructions, and other parameters
media	Packet or cell ingress from physical network or egress to physical network
switching fabric	Packet transfer to an output port
PCI bus	Allows host computer to control the APP550
scheduler	Access to external scheduler
coprocessor	Access to external coprocessor hardware

**Figure 17.7** The purpose of external connections on Agere's APP550 network processor.