

Numeric Value	Meaning
0	Slow ingress file
1	Slow egress file
2	Fast ingress file for Port 1
3	Fast ingress file for Port 2
4	Fast egress file

Figure 23.3 Numeric values used in the configuration file. Intel's SDK uses the values when choosing how to assign microblocks to microengines.